



Switches



6A Plate switches

GSW1G1W	1 gang 1 way
GSW1G2W	1 gang 2 way
GSWA1G2W	1 gang 2 way + architrave switch
GSW2G2W	2 gang 2 way
GSWA2G2W	2 gang 2 way + architrave switch
GSW3G2W	3 gang 2 way
GSW4G2W	4 gang 2 way
GSWISO	TP Isolator
GSWINT	1 gang intermediate

20A Double Pole switches

GSWDP20A	DP switch
GSWDPN20A	DP switch + neon
GSWDP20AFO	DP switch + flex outlet
GSWDPN20AFO	DP switch + neon + flex outlet

45A switches & cooker panels

GCKR45A	1 gang DP plate
GCKRN45A	1 gang DP plate + neon
GCKR45A2G	2 gang DP plate
GCKRN45A2G	2 gang DP plate + neon
G45ACCU	Cooker panel
G45ACCUN	Cooker panel + neon
G45CX	Cooker connection unit

Ceiling switches

GSWPULL6	6A 1 way
GSWPULL2	6A 2 way
GSKPULL45N	45A DP + neon

Shaver Socket



GSHVSKT
dual
voltage

Sockets




13 Amp

GSKTSW1G	1 gang switched
GSKTSW2G	2 gang switched
GSKTSW3G	3 gang switched
GSKT1G	1 gang unswitched
GSKT2G	2 gang unswitched

Round Pin

GSKT2A1G	2 amp unswitched
GSKT5A1G	5 amp unswitched

Fused Connection Units



GSPUR	Unswitched spur
GNSPUR	Unswitched spur + neon
GSWSPUR	Switched spur
GSWNSPUR	Switched spur + neon
GFOPLATE	Front entry flex outlet

Lampholders



Pendant and Lampholders

GPEND6	Pre-wired 6"
GPEND9	Pre-wired 9"
SRO	Ceiling Rose
GLHC	Lamp Holder

Battenholders

GBAT	Pre-wired
GABAT	Pre-wired Angled

Surface Pattress Boxes




GPAT1G16	16 mm 1 gang
GPAT1G16A	16 mm 1 gang architrave
GPAT2G16A	16 mm 2 gang architrave
GPAT1G25	25 mm 1 gang
GPAT2G25	25 mm 2 gang
GPATDG25	25 mm dual pattress
GPAT1G47	47 mm 1 gang
GPAT2G47	47 mm 2 gang
GPAT3G25	25 mm 3 gang

Coaxial Sockets



GSKTCOAX	1 gang socket
GSKTCOAX2G	2 gang socket

Blank Plates



GBLANK1G	1 gang blank
GBLANK2G	2 gang blank

**15 year
guarantee**