



Switches



10A Plate switches

GU1212	1 gang 2 way SP
GU1222	2 gang 2 way SP
GU1232	3 gang 2 way SP
GU1242	4 gang 2 way SP
GU1262	6 gang 2 way SP
GU1213	3 pole isolator
GU1214	1 gang intermediate

20A DP switches

GU2210	DP switch
GU2211	DP switch + neon
GU2213	DP switch + flex outlet
GU2214	DP switch + neon + flex outlet

45A switches

GU4221	2 gang DP plate + neon
GU4201	Cooker panel + neon

Socket Outlets




13 Amp

GU3250	1 gang unswitched
GU3260	2 gang unswitched
GU3210	1 gang switched
GU3210D	1 gang DP switched
GU3220	2 gang switched
GU3220D	2 gang DP switched

Round Pin

GU3270	1 gang 2 amp
GU3280	1 gang 5 amp


Floor Sockets



13 Amp

GU3251	1 gang unswitched
GU3252	2 gang unswitched

BT Sockets




GU7261	Single BT master
GU7262	Single BT slave

13A Fused Connection Units



GU5200	Unswitched
GU5203	Unswitched + flex outlet
GU5210	Switched
GU5213	Switched + flex outlet
GU5211	Switched + neon
GU5214	Switched + flex outlet + neon

Shaver Socket



GU7290	dual voltage
--------	--------------

Blank Plates




GU8210	1 gang
GU8220	2 gang

Electronic Dimmers



GU6212E	1 gang 300w/VA
GU6222E	2 gang 300w/VA

Coaxial Sockets



GU7210	Single TV / FM
GU7220	Twin TV / FM
GU7230	Single satellite
GU7240	Twin satellite/co-axial
GU7221	Diplex
GU7281	Triplex

Dimmers



GU6211	1 gang 1 way 400w
GU6212	1 gang 2 way 400w
GU6222	2 gang 2 way 250w
GU6232	3 gang 2 way 250w
GU6242	4 gang 2 way 250w