



Plugs

Amps	Poles	Volts
16	2P. + E	110/130
16	2P. + E	220/250
32	2P. + E	220/250
16	4P. + E	380/415
32	4P. + E	380/415



Wall Sockets

Amps	Poles	Volts
16	2P. + E	110/130
16	2P. + E	220/250
32	2P. + E	220/250
16	4P. + E	380/415
32	4P. + E	380/415



Coupler

Amps	Poles	Volts
16	2P. + E	110/130
16	2P. + E	220/250
32	2P. + E	220/250
16	4P. + E	380/415
32	4P. + E	380/415



Switched Sockets

Amps	Poles	Volts
16	2P. + E	110/130
16	2P. + E	220/250
16	4P. + E	380/415



RCD Sockets

Amps	Poles	Volts
16	2P. + E	110/130
16	2P. + E	220/250
16	4P. + E	380/415